

**ULTRA-COMPACT UNCOOLED
THERMAL CORE**

Xenics
EXOSENS GROUP

MicroCube XP 640 (NEW)



*ULTRA-COMPACT VGA CORE WITH
EXTREME PERFORMANCE*

KEY FEATURES



ULTRA-SWAP THERMAL CORE



**ADVANCED SHUTTERLESS IMAGING
WITH EMBEDDED CORRECTION**



**CONTOUR ENHANCEMENT: SHARPER DRI
AND SUPERIOR OBJECT CLARITY**



**COLUMN AND TEMPORAL DENOISING:
NETD halved from 40 mK to 20 mK**



**CONTRAST SHARPNESS CORE FOR
AUTOFOCUS MANAGMENT**

The MicroCube XP (Extreme Performance) 640 delivers 640×480 resolution with a 12 μ m pixel pitch and exceptional thermal sensitivity (NETD <20 mK), all in an ultra-compact form.

With fast startup (<0.7s), shutterless operation, and enhanced temperature stability, it ensures rapid, reliable performance. Contour enhancement provides improved contrast, DRI, and target visibility. Optimized for defense and mission-critical applications, its compact SWaP design and versatile interfaces enable seamless integration.



exosens.com

MicroCube XP 640 (NEW)



KEY PERFORMANCES

| | |
|-------------------------------|--|
| Sensor | Micro-bolometer technology |
| Resolution / Pixel Pitch | 640 x 480 pixels / 12 μ m |
| Spectral Range | 8 – 14 μ m |
| Max NETD (F/1 ; 300K ; 30 Hz) | < 20 mK with denoising |
| Operating temperature range | -20°C to +60°C |
| Power consumption (DF40) | < 1.2 W |
| Qualification | MIL-STD-810G – Method 514 Vibration: 10Hz - 2kHz 13.95g per axis 10h per axis |

FUNCTIONS & INTERFACES

| | |
|-------------------------------|--|
| Image processing | BPC (Bad Pixel Correction), NUC (Non Uniformity Correction), Shutterless NUC |
| Image optimisation | AGC (Automatic Gain Control) |
| Output options | MIPI-CSI, DF40 |
| Dimensions (L x W x H) (DF40) | 22.0 x 22.0 x 26.8 mm ³ |
| Weight (DF40) | < 25 gr |

advancedimaging@exosens.com



exosens.com

EXOSENS
REVEAL THE INVISIBLE

© Xenics. The information furnished is believed to be accurate and reliable but is not guaranteed and is subject to change without notice. No liability is assumed by Xenics nor by any Exosens Group companies. Performance data represents typical characteristics as individual product performance may vary. Customers should verify that they have the most current Xenics product information before placing orders. Texts and pictures may not be considered as contractually binding. This document may not be reproduced, in whole or in part, without the prior written consent of Xenics.